

RENOLIT EXOFOL Films. Cleaning made simple.



When something accidentally spills during installation.

Wherever there is construction, there is dirt, and a splash of plaster or paint can easily land on that brand new window frame. Care should be taken when cleaning **RENOLIT** EXOFOL films, as abrasive or corrosive products such as scouring agents, solvents or sharpedged tools can cause permanent damage.

Hot tap water and ordinary washing-up liquid are sufficient to remove tile adhesive, paint or plaster residues. In these cases, use plenty of water and be patient. Soak the dirt thoroughly then rinse away the loosened particles, otherwise it acts like sandpaper.





For the annual spring clean.

With **RENOLIT** EXOFOL films, having clean window frames is a foregone conclusion, because dirt particles have difficulty sticking to their surface.

Regular household cleaning is easy. Hot tap water, a soft brush or sponge and a squirt of washing-up liquid are all that is needed to remove summer dust or winter dirt. Under no circumstances should you scrub or rub, otherwise the top layer of the film will be damaged and its protective effect impaired.





RENOLIT SE

Market Unit Exterior Solutions Horchheimer Str. 50 67547 Worms | Germany Phone: +49.6241.303.1040 Fax: +49.6241.303.18.1139

RENOLIT Cramlington Limited Station Road Northumberland, NE23 8AQ Cramlington | United Kingdom Phone: +44.1670.718222 Fax: +44.1670.590096

exteriorsolutions@renolit.com www.renolit.com/exteriorsolutions



